

Recommended Parts List

½ - 10 Ton Systems:

<u>Part Number</u>	<u>Description</u>
006256	Motor Starter / 24 Amp Contactor 110V Coil (Pump/Motor)
006257	40 Amp Contactor 110 V Coil (Compressor)
006260	1 – 2.9 Amp Overload
006261	1.6 – 5 Amp Overload
006263	3.7 – 12 Amp Overload
008021	0-160 PSI Pressure Gauges, Suction and Discharge
018246	Pump seal Kit for Scot Pump
022038	Start/Stop Button
023089	Thermometer
040002	Type J Thermocouple

15 and 20 Ton Systems:

<u>Part Number</u>	<u>Description</u>
006256	Motor Starter / 24 Amp Contactor 110 V Coil (Pump/Motor)
006257	40 Amp Contactor 110V Coil (Compressor)
006298	50 Amp Contactor 110V Coil (Compressor)
006263	3.7 – 12 Amp Overload
008021	0-160 PSI Pressure Gauge, Suction and Discharge
018246	Pump seal Kit for Scot Pump
022038	Start/Stop Button
023086	Thermometer
040011	Type J Thermocouple