

Eurotherm 2200 Series Procedure to Set High/Low Temperature Range

Press "Page" button...until "ALCS" appears in the upper display.

Press "scroll" button...until "code" appears in the upper display.

Enter "2150"... "PASS" will appear in the lower display.

Press "scroll" button...until "Go to" appears in the upper display.

Press "up" button...until "FULL" appears in the lower display.

Press "Page" button...until "SP" appears in the upper display.

Press "scroll" button...until "SP L" appears in the upper display.

Press "up" or "down" buttons to achieve the desired "set point low limit".

Press "scroll" button...until "SP H" appears in the upper display.

Press "up" or "down" button to achieve the desired "set point high limit".

Press "page" button...until "ALCS" appears in the upper display.

Press "scroll" button...until "code" appears in the upper display.

Press "up" button...until "0" appears in the lower display.

Pressing the "page" and "scroll" simultaneously, returns the controller to the normal display.



MOKON
CUSTOMER SERVICE
2150 Elmwood Ave • Buffalo, New York 14207
Phone (716) 876-9951 • FAX (716) 874-8048
custserv@mokon.com
www.Mokon.com

9/10/2004